

Installation Instructions

009718-01-01 – Low PIM Cable Support Bracket, Small

009718-02-01 – Low PIM Cable Support Bracket, Large

STEP 1

Attach threaded rods to bracket
(Torque greater than 10 Ft-lb)

STEP 2

Attach clamp set to pole

STEP 3

Attach cable clamps to threaded rods

Torque: 10 Ft-lb all connections
(ConcealFab Tool PN: 900053)



Document Number - 009718-IG

